

## INTENDED USE

Bracing kit for stabilizing LOE/TOE cable trays from central support brackets. Allows for uneven loading of central support and gives increased rigidity.

## INSTRUCTION FOR USE

Attach the U bolt to one of the brackets and fix to the rock bolt or central support.  
Attach the other bracket to the side of the ladder requiring extra support with self locking bolts (Not included - for LOE55/75 M6, for LOE/TOE 2xM10 required)

Attach both brackets together with the threaded rod. One nut should be on each side of the bracket. Tension the rod to support the load and lock both nuts onto the bracket.

