

INTENDED USE

Flexible Edge Protection beading to prevent damage to cables when entering or exiting over edges. Typical bending should not exceed 90 degrees.

INSTRUCTION FOR USE

Cut to size and form into place by hand. Only if necessary use a soft faced hammer to ensure fit, however use great care not to damage the protection. When fitting around 90 degree sharp edges, the edge must be rounded with minimum 10mm radius.

Note - where the cut is made it will expose the internal metal structure. The metal piece at the cut ends must be removed with pliers.



If fitting round a 90° corner, the edge should be rounded with a 10 mm radius to fit smoothly.

