


## INTENDED USE

UNO bracket for connecting U-41-2 UNO to other UNO sections.


## INSTRUCTION FOR USE

Fix UNO nuts or UNO card in the channel.  
Attach the bracket connecting the sections.  
Adjust and tighten securely.


UNO U-Bracket for U-41-2




Typical installation



Fitting UNO nut with UNO card



Fitting UNO nut with spring



User Guide for Bolts:  
Recommended Torque