USER GUIDE · OE TELESCOPIC SPLICE CONNECTOR



OE - Fixings

INTENDED USE

Splice connectors which can be extended to fill installation gaps between OE sections, for example when marrying modules together.

INSTRUCTION FOR USE

Attach the parts together loosely using self locking bolts. Adjust and tighten securely.









