

## INTENDED USE

Hurricane cover clamps for OE ladder straight lengths and fittings where high wind loadings occur.

## INSTRUCTION FOR USE

Covers can be fitted as standard using proprietary cover clamps, and further secured using hurricane clamps at joints or at set centres.

Before fitting the cover, fit bolts in the cover holes and screw nut in place.

Attach the covers and fasten with proprietary cover clamps on the sides.

Fit the hurricane clamp over the covers and attach the the nuts on the hurricane clamp top.

Fix the sides of the clamps onto the rails with self locking bolts.

For widths 450 mm or less where the covers are 3 m long, support the centre with an additional Hurricane Clamp to the side rails.

