USER GUIDE · SMARTCLEAT TO MEKANO



INTENDED USE

The intended use of the SmartCleat is for retention of both low voltage and high voltage cables of diamater ranging from 25mm to 99mm.

INSTRUCTION FOR USE

Before the installation make sure that the suitable adapter is used for the particular cleat-support combination. For more information on our cleat adapters please refer to ØI-RD-UG-EN-0436 SmartCleat Adapter Matrix.

- 1. Fit the square washer underneath the cleat.
- 2. Insert the bolt through the cleat and washer.
- 3. Place and hold the second square washer inside the channel.
- 4. While holding the cleat-washer-bolt assembly together, fit the bolt through the channel and second washer.
- 5. Adjust and tighten the supplied M6 anti-vibration nut to 8Nm.

Single cleats in the range 1x80-1x99, and trefoil cleats in the range 3x96-3x99 requires two sets of adapters.

