

INTENDED USE

Cable retention cleat used typically to hold high voltage trefoil and single cables in place during operation, and during short circuit events.

INSTRUCTION FOR USE

1-2. Attach the cleat using the supplied adapter under the rung with supplied locking bolt. Tighten the M6 nut to 8-10 Nm.

3. Place the cables in the Smart Cleat.

4-5. An Allen key 5 mm or other tool can be placed in the center hole to align the outer two bolt holes for smooth installation. Tighten first by hand.

6. Tighten the M8 Allan bolts to 10-12 Nm. It is recommended to use hand tools.

7. If using powered screwdrivers, use slow speed.

8. For vertical installation/ runs we recommend using 3mm EPDM liner at least on one cleat side.

